




VEID ENTERPRISES PTE LTD
642 Rowell Road #02-119,
Singapore 200642.

Tel: +65 6599 6805 Fax: +65 6251 1287
Email: sales@veid.net

How to setup LED display panel

LED Solution Architecture





VEID ENTERPRISES PTE LTD
642 Rowell Road #02-119,
Singapore 200642.

Tel: +65 6599 6805 Fax: +65 6251 1287
Email: sales@veid.net

- 1) Check the model number behind the LED Module



- 2) Go to <http://www.qllcd.com/service/download>



VEID ENTERPRISES PTE LTD
642 Rowell Road #02-119,
Singapore 200642.

Tel: +65 6599 6805 Fax: +65 6251 1287
Email: sales@veid.net

3) Key in M23110439 and download the document.

下载中心

DOWNLOAD CENTER

一键调试

M23110439	查询	系统厂家	系统卡型号
--	-----------------------------------	-----------------------------------	------------------------------------

产品	芯片组合	系统厂家	系统卡型号	产品说明	加载文件	软件	方案
室内表贴Q2.5AB32	SM16389+SM5368	卡莱特	V5A-75B/V5A-75E	产品说明书.docx	Q2.5S20B32V2-----16389+5368-----4200HZ-----10.81.rcvbp	Q2.5S20B32V2-----16389+5368-----4200HZ-----10.81.zip 放系统 QLplayer_6.8.42749.exe	模组方案

4) Unzip and you will see 2 files.

Name	Date modified	Type	Size
Today			
E320_PCB6.0_PWM_FPGA10.81_20230907.hex	12/3/2024 3:01 pm	HEX File	705 KB
Q2.5S20B32V2-----16389+5368-----4200HZ-----10.81.rcvbp	12/3/2024 3:01 pm	RCVBP File	5 KB

5) Select *****.hex file to upgrade receiver.



VEID ENTERPRISES PTE LTD
642 Rowell Road #02-119,
Singapore 200642.

Tel: +65 6599 6805 Fax: +65 6251 1287
Email: sales@veid.net

